

OPTONICA

PORTABLE PARTY BLUETOOTH SPEAKER

USER MANUAL

GENERAL INFORMATION

This product is a well-designed portable portable party bluetooth speaker which applies to household, outdoor travel, office and other places. It offers you a chance to indulge yourself in music at any time and place, and provides perfect sound service to your computers, digital media players, mobile phones and other audio-visual products.

FUNTCTION OVERVIEW

[CHARGEABLE BATTERY] - Chargeable battery included; environmental, economical and functional.

[AUDIO INPUT] - A stereo audio input jack; enable the sound source connection with computers, digital media players, mobile phones and other audio-visual products.

[MP3 PLAYER] - Enable directly playing MP3 files in TF memory card and U Disk.

[INTELLECTIVE CHARGING] - Wiring with USB jack, enables charging by connecting with USB jack of computer or cell phone charger.

DEFINITION OF BUTTON

1. "OFF/ON" Button: Power switch.
2. "◀ /-" Button: Short press for last item or last channel, long press for turning down the volume.
3. "▶ /+" Button: Short press for next item or next channel, long press for turning up the volume.
4. "⏮" Button: Short press for Play/Pause.
5. "M" Button: Mode shift button.
6. "DC 5V" port: Power input + earphone jack for listening to music or radio channel. Power input jack with USB wiring, enables charging by connecting with USB jack of computer or cell phone charger.
7. "TF" port: Insert TF card for MP3 music playing.
8. "AUX" port: Audio input jack, enable the sound source connection with computers, digital media players.
9. "USB" port: Insert U disk for MP3 music playing.

CHARGING METHOD

One end of wiring be inserted in DC5V, another end with USB jack be inserted in USB jack of PC or other charging with standard 5V 500mA jack.

LOW POWER

When low power occurs and system been power off automatically, please charge in time; not use this product for a long period, please charge at least once a month so as to lengthen battery's life.