

Attention:

- 1.Loosen the cap of the fixing fixture, then adjust the flexible track.
- 2.Loosen connection cap of the lamp, then move it for adjustment.
- 3.The weight of all lamps between two fixing should ≤3KG.
- 4. The total power of lamps shall not exceed 80% of driver's power. Please make sure driver output is same as fixture input(DC48V/ DC24V)before install the lamps.
- 5.Don't pull the flexible track after installation.
- 6.Note: Different spatial shapes are determined by the location of the fixed point, which should be installed according to the design drawing.
- 7.Due to voltage drop considerations, the track length from the driver to the terminal end to a maximum of 15 meters